


Wi-Fi evohome Controller (ATC928G3000)



**Wi-Fi evohome Controller
(ATC928G3000)**

**Wireless Relay Box
(BDR91) Boiler**



To bind a **Wireless Relay Box (BDR91)** to a **Wi-Fi evohome Controller (ATC928G3000)** to control a boiler...

On the **evohome Controller**

- 1 Press and hold **SETTINGS** for 5 seconds
- 2 Press the green tick
- 3 Press **SYSTEM DEVICES**
- 4 Press **BOILER CONTROL**
- 5 Press **WIRELESS RELAY BOX**

On the **Wireless Relay Box**

- 6 Press and hold the button for 15 seconds (until the red LED blinks rapidly) to clear any previous binding data
- 7 Press and hold the button again for 5 seconds (until the red LED blinks slowly)

On the **evohome Controller**

- 8 Press the bind button

You should receive a SUCCESS message on the evohome Controller and the LED on the Wireless Relay Box should stop blinking and turn OFF. If not, go back and re-bind.

AutomatikCentret

Strandvejen 42 ♦ Saksild ♦ 8300 Odder
86 62 63 64 ♦ www.automatikcentret.dk
info@automatikcentret.dk